


AIRPORT DIAGRAM

18088

DANIEL K INOUE INTL (HNL) (PHNL)

AL-754 (FAA)

HONOLULU, HAWAII



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES. READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

JOINT BASE PEARL HARBOR-HICKAM

BASE OPS

127.9 251.15
HONOLULU TOWER
118.1 257.8
123.9 273.575 (RWY 08R-26L)
GND CON
121.9 348.6
GND CON (RAMP CON)
121.8
CLNC DEL
121.4

RWY 04L-22R
PCN 31 F/B/X/T
S-100, D-200, 2D-400,
2D/D1-450, 2D/2D2-850

RWY 04R-22L
PCN 57 F/B/X/T
S-100, D-200, 2D-400,
2D/D1-450, 2D/2D2-850

RWY 08L-26R
PCN 79 R/B/W/T
S-100, D-200, 2T-345,
2D-400, 2D/D1-400,
2D/2D2-780, C5-840

RWY 08R-26L
PCN 98 F/B/X/T
S-80, D-170, 2D-400,
2D/D1-415, 2D/2D2-780, C5-780

PAC, 29 MAR 2018 to 24 MAY 2018

PAC, 29 MAR 2018 to 24 MAY 2018

AIRPORT DIAGRAM

18088

DANIEL K INOUE INTL (HNL) (PHNL)

HONOLULU, HAWAII